

Rita's Water Ice Bag Adaptor Assembly

Models: 88TRMT, 99TRMT, Gen5099, Gen5400, Ges5400, Fuzionate, 15RMT, 30TRMT



You first need to cut your existing plastic hose into two pieces. This will give you the proper hose length and will also give you a spare hose.

Step 1: Layout your existing hose

Step 2: Fold your hose in half ensuring that the top end of the hose sides are even.

Step 3: Find the middle point of your hose and cut the hose in half.



Step 4: Insert one end of the hose onto the mix cane. Hand tighten clamp. This end will be placed into the port assembly on your mix transfer system.



Step 5: Insert the opposite end of the hose onto bag adaptor. Hand tighten clamp. Insert duck bill into the bag adaptor.



Step 6: Place mix cord onto the silver probe end on both the mix cane and bag adaptor. When finished, your assembly should look as pictured with the spare hose as an extra part for future use.