

GES5099 BAG ADAPTOR INSTRUCTIONS



The bag adaptor for all “GES5099” units with pump forward design will feature the following parts:

1. Small hose clamp
2. Connector assembly
3. Duckbill valve



- First step is to insert the duckbill valve into the connector assembly.
- When installing make sure that the “duckbill” section of the valve is inserted into the chamber of the assembly and the “feet” of the valve sit outside the bottom of the connector assembly chamber.



- The connector assembly will connect to the clear tube coming off the port assembly on your mix transfer system.
- This is the stainless port that is connected to your red line mix transfer hose.



- Slide the small end of the connector assembly onto the end of the clear air hose and use the hose clamp to tighten. Hand tight is sufficient.
- The large end of the connector assembly will be placed into your custard bag